
HDSECO-1 - 240V/60HZ



No.	Description	Part No.	Qty
1	Left side plate		1
2	Right side plate		1
3	Back seal plate		1
4	Top cover assy		1
5	Front decoration plate		1
6	Motor back cover		1
7	Housing		1
8	Heating element pressing plate		2
9	Chimney assy	801029008021	1
10	Air deflector assy	801005033007	1
11	Control panel		1
12	Air deflector tubing	802029008147	1
13	Power cord sleeve	70100700773	1
14	Power cord for three phase	70100501773L	3m
15	Wire piping adaptor	70202014273	2
16	Wire piping	70201902664	3m
17	Terminal block, 4 pins	70100702873L	1
18	Terminal block, 6 pins	70100702864L	1
19	AC Contactor	70100901282L	2
20	Heating indicator, yellow	70101301628L	2
21	Power indicator, green	70101301419	1
22	Switch	70100801419	4
23	Timer	70101200282	1
24	Timer knob	70101104964 +70101500664	1
25	Digital thermostat	70100302346L	1
26	Thermostat probe	70201700573L	1
27	Thermostat knob	70101105819L +70101500664	1
28	Buzzer	70101000028	1
29	Capacitor	70100102791L	1
30	Motor reverse controller PCB	70101500873L	1
31	Fuse hodler	70101301719L	1
32	Fuse	70101301728L	2
33	Micro switch	70100801619L	1
34	Motor	70100102773L	1
35	Motor insulation	70202018819	4
36	Wheel blower	70200300673	1
37	Back heating element 3300W	70100413082L	1
38	Bottom heating element 3300W	70100413100L	2
39	Hi limit, auto reset, 350°C	70100302437L	1
40	Chamber Lamp base	70101300355	1

No.	Description	Part No.	Qty
41	Chamber Lamp	70101301746L	1
42	Chamber Lamp cover assy	801029008009	1
43	Door trip switch pushing plate assy	801029008022	1
44	Door trip switch	70100800791	1
45	Left door assy	801029008018	1
45	Door latch assy	801029008017	2
46	Right door assy	801029008020	1
47	Baking grid	70201105782	3
48	Side shelf	70201105773	2
49	Control panel sticker	70301247746L	1
50	Leg with caster assy	801029001007	4