
HDSHD-48
120V-60HZ

No.	Description	Part No.	Qty
1	Top plate assy - Cold-rolled sheet δ=1.0		1
2	Decorative lamp cover - Plastic 89cm	70201001064	1
3	Water basin - 1/9*2.5"(156*92mm)	70201200346	1
4	Fixation screw for heater cover plate - SS	70202102928	6
5	Heater cover plate - SS430 δ=1.0	802001003017	1
6	Bottom plate assy - SS430 δ=1.0	801001003004	1
7	Chute - 823mm	70200700646	2
8	Heater - 120V	70100402564	1
9	Upholder for heater supporting plate - Aluminized δ=1.0		4
10	Screw - SS	70202102764	10
11	Flat washer - SS	70202126955	10
12	Spring washer - SS	70202127791	10
13	Nut - SS	70202100482	10
14	Power cord	70100500164	1
15	Power switch	70100800091	1
16	Heating indicator - 110V	70101300200	1
17	Thermostat knob dial base - 85-185°F ¢58	70101102246	1
18	Thermostat knob - ¢41	70101103328	1
19	Nut - SS	70202102737	2
20	Screw - SS	70202116473	4
21	Control panel - Cold-rolled sheet δ=1.0		1
22	Thermostat - 85℃	70100302164L	1
23	Power cord jacket	70100700782	1
24	Temperature displayer - 20-120℃	70100200346	1
25	Rear bottom plate assy		1
26	Side glass fixation plate - SS430 δ=1.0		4
27	Bolt - SS	70202107137	4
28	Screw - Galvanized	70202126246	4
29	Rubber foot - Rubber	70200900273	4
30	Nut - Galvanized	70202100055	4
31	Heater supporting plate - Aluminized δ=1.0		1
32	Heater installation plate - Aluminized δ=1.0		1
33	Left shelf supporting plate - SS430 δ=1.0		3
34	Handle seal - Rubber	70200200155	1.6
35	Handle for front door glass	70200700191	2
36	Front door glass - δ=4.0	70201000737	2
37	Grid(large) - A3 nickel coating	70201100837	1
38	Right shelf supporting plate - SS430 δ=1.0		3
39	Grid(medium) - A3 nickel coating	70201100828	1
40	Grid(small) - A3 nickel coating	70201100819	1
41	Supporting column of the side plate - SS430 δ=1.0	802001001017	4
42	Right chamber light holder - PVC δ=1.0	70200701073	1
43	Side glass - Tempered glass δ=5.0	70201000746	2



No.	Description	Part No.	Qty
44	Screw - Galvanized		2
45	Handle for back door glass	70200700173	2
46	Back door glass - δ=4.0	70201000728	2
47	Ballast - 120V	70101001628	2
48	Starter - 120V	70101301582L	2
49	Starter holder	70101300564	2
50	Lamp - 15W/220V	70101300400	2
51	Lamp holder - Ceramic	70101300355	2
52	Main shelf assy		1
53	Decorative lamp holder	70101300528	4
54	Decorative lamp - 8W	70101300419	2
55	Left chamber light holder - PC δ=1.0	70200700619	1